

DETROIT RADIANT PRODUCTS

LS & LD Baffle Installation Sheet

Insert assembled baffles with the HEAT baffle preceding the PRES-SURE baffles (fig. 1). Allow for turbulator fins, so that the key hole is inserted first. All baffles must be placed vertically in the last radiant tube/heat exchanger (fig. 2).

If the heater is installed with a U or Elbow fitting all baffle must still re-main. There may be some instances

where the baffle will be cut into two sections. Place as much baffle as possible downstream of the U or Elbow and the remainder of the baffle just before the U or Elbow fitting.

