


# Tube Heater Accessory Sheet

## Combustion Chamber Heat Diffuser Kit (P/N: CCHD) Installation Instructions

### Kit Contents

- (2) 5' Diffuser (A)
- (3) Mounting Clamps (B)
- (3)  $\frac{5}{16}$ " - 18 x  $\frac{3}{4}$ " Hex Head Screw (C)
- (3) Square Washer (D)
- (3)  $\frac{5}{16}$ "-18 x 1  $\frac{1}{2}$ " Round Head Screw(E)
- (3)  $\frac{5}{16}$ "-18 Hex Nut(F)
- (3) Lock Washer for  $\frac{5}{16}$ " Screw(G)

Figure 1 • Kit Contents



### Installation Instructions

- 1 Position one 5' diffuser on top of the other by aligning the slots at each end.
- 2 Secure the middle mounting clamp to the diffusers by screwing the  $\frac{5}{16}$ "-18 x  $\frac{3}{4}$ " hex head screw through the square washer and into the nutsert.
- 3 Repeat previous step for the remaining mounting clamps on each end of the assembly. **NOTE:** Refrain from fully torquing the screws until fully assembled to allow the tubes to align the diffusers.
- 4 Secure each mounting clamp onto the radiant tubes using the  $\frac{5}{16}$ "-18 x 1  $\frac{1}{2}$ " round head screw, lock washer, and hex nut. The position of the assembly can be determined by the user to meet demands.

Figure 2 • Full Heater View

